



1
Remove the pedals - both pedals will undo backwards towards your rear wheel



2
Remove the saddle & seatpost



7
Fasten wheels in position using the supplied zip ties



8
Repeat steps 6 & 7 for remaining wheel



9
Your bike is now ready to fit into the Pod



3
Remove the handlebars - Either by taking off the face plate of the stem or by undoing the rear pinch bolts that attach the stem to the steerer



10
Cover both wheels with foam sheets. Place bike in the center of the Pod



11
Secure the bike in position using the internal pod straps. Please note there are 4 straps and 5 fixings points, so you can move the straps around if necessary



5
Remove both wheels and skewers. You may wish to unbolt your rear mech if you have a very large bike



6
Place the wheels in the Pod. The cassette should face outwards. You may wish to partly deflate the tyres if required




13
Ensure clasps are shut correctly. You must ensure they are locked when travelling



14
Attach clasp on handle



15
Your Bike Pod Pro is now ready



**Polaris Apparel Ltd,
VeloCity Point,
Wreakes Lane,
Dronfield,
Derbyshire
S18 1PN**

**Tel: +44 (0)1246 29 11 00
Fax: +44 (0)1246 41 00 70**

Bike Pod Pro Instruction Guide

WWW.POLARIS-BIKEWEAR.CO.UK WWW.POLARIS-BIKEWEAR.CO.UK

Follow us on twitter "@polarisbikewear"